

Corporate Profile Handheld Labeling Solutions

SATO is a pioneer and leading global provider of integrated Automatic Identification and Data Collection solutions that leverage barcode and **RFID** technologies.

SATO manufactures innovative, reliable autoidentification systems and offers complete solutions to businesses by integrating hardware, software, consumables and maintenance services. SATO's solutions enable businesses to realize precision, labor and resource savings that help preserve the environment and deliver peace of mind to consumers. All of which contribute to the development of a sustainable world.

Today, SATO continues its tradition of designing and manufacturing high quality printing systems, including its legendary line of hand labeler products that deliver reliable, unparalleled performance.

SATO AMERICA CORPORATE

10350-A Nations Ford Rd Charlotte, NC 28273 Phone: (704) 644-1650 Fax: (704) 644-1662 sales-sallc@sato-global.com

LABEL MANUFACTURING, SERVICE & SALES

CANADA

UNITED STATES MEXICO CENTRAL AMERICA

CARIBBEAN

©2017 SATO America. All rights Reserved. Rev A • Specifications subject to change without notice • Any unauthorized reproduction of this content, in part or whole, is strictly prohibited • SATO is a registered trademark of SATO Corporation and its subsidiaries in Japan, the U.S. and other countries. All other trademarks are the property of their respective owners.

Maintenance

- Scheduled cleanings are highly recommended • to avoid troublesome operation caused by paper dust and adhesive residue
- Clean print head with a soft, dry toothbrush
- Do not use lubricants or detergents to clean your • Handheld Labeler
- Do not re-ink used ink roller •
- Do not place the tool, label or ink roller in a high humidity environment or above 40°C/104°F

Troubleshooting

Labels are not properly fed

- Squeeze the trigger firmly and completely
- Re-load labels according to the instructions in this guide
- Confirm that you are using genuine SATO labels
- Be sure the tools have been properly maintained ٠
- Check to see if the labels are damp

No print appears on the labels

- Use a new ink roller
- Squeeze the tool handle lever completely to • print a label
- Use genuine SATO ink rollers •
- Push pointer back firmly to it's original positon

There are dots and dust spots on labels

• Clean the application roller and printhead to remove any stray ink and dust

HANDHELD LABELING SOLUTIONS



INSTRUCTION MANUAL PB2-230 PB2-180



Handheld Labeling Solutions

SATO's PB2 Series of handheld labelers are equipped with commonly used expressions, larger font size and a wide-open path for easy label loading. The PB2 Series is intuitive to operate and user friendly.



Loading Label Rolls



Lift the label roll cover by gently pressing in on the marked grips and lifting up.



After opening the door, gently lift the pressure plate and pull to open up the entire tool.



Gently feed the labels through the tool from the top.



Once loaded, pinch the levers on either side of the tool and slide the label roll into place. Release the levers, tightly close the label roll cover.



Turn the tool over and lift up on the marked tab on the tool's door to open up the bottom.



Take the roll of labels and remove one round, eliminating any glue simplifying the loading process.



The labels will slide through the tool and come out from the bottom.



After closing the cover, flip the tool upside down. Pull the labels out about 6", aligning the labels within the guide. Tightly close the pressure plate.



Pull the labels back, towards the tool handle, making sure to align the tabs of the labels with the knobs on the reel.



Close the door on the bottom of the tool by gently lifting the door while pushing it down into place. The tool is now ready to use.

Replacing Ink Roller





Gently slide the ink

roller free from the

assembly.

At the front of the
tool, pinch the
top, ribbed leverTilt the assembly
back and lift up to
remove from the
tool.



lower lever.



6

 Slide the fresh ink
 Pinching the levers

 roller into place,
 of the assembly

 making sure the arrow
 together, slide the

 indicators align.
 assembly into place.

Once in position, release the levers and the assembly will snap into place.

Setting Print Characters



Pull the pointer in or out as required and rotate to select print character.



Push the pointer back to its original position.