




Parts List

For printer model:

TG3 Series



PN: 9001227(A)

Copyrights

The contents of this document are proprietary information of SATO Corporation and/or its subsidiaries in Japan, the U.S and other countries. No part of this document may be reproduced, copied, translated or incorporated in any other material in any form or by any means, whether manual, graphic, electronic, mechanical or otherwise, without the prior written consent of SATO Corporation.

Limitation of Liability

SATO Corporation and/or its subsidiaries in Japan, the U.S. and other countries, makes no representations or warranties of any kind regarding this material, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose. SATO Corporation shall not be held responsible for errors contained herein or any omissions from the materials or for any damages, whether direct, indirect, incidental or consequential, in connection with the furnishing, distribution, performance, or use of this material.

SATO Corporation reserves the right to change or improve this product and document without notice.

Trademarks

SATO is a registered trademark of SATO Corporation and/or its subsidiaries in Japan, the U.S and other countries.

SATO America, Inc.
10350 Nations Ford Road
Charlotte, NC 28273
Main Phone: (704) 644.1650
Technical Support: (704) 644.1660
Technical Support Fax: (704) 644.1661
E-Mail: satosales@satoamerica.com
www.satoamerica.com
© Copyright 2010 SATO America, Inc.
All rights reserved.

ENGINE ASSEMBLY




Figure PL1a, Engine Assembly

ENGINE ASSEMBLY (PL1A)		
ITEM	PART NUMBER	PART DESCRIPTION
13	K00285000	STEPPING MOTOR
41	MD3401222	PAN HEAD SCREW
44	MD4300522	PAN HEAD SCREW +SW +WL
48	MD4400622	PAN HEAD SCREW +SW +WL
61	MJ1400524	HEX W-POINT SCREW
66	ND0040030	E SNAP RING
80	P13863010	TENSION ROLLER
136	P28000010	POWER ROUTE (BASE) B
138	P28005000	TENSION PLATE A
163	P28095000	MOTOR PULLEY (22)
168	P28132000	TENSION SHAFT A
177	P28147000	SHAFT (CUT PULLEY B)
178	P28158000	TENSION SHAFT C
187	P28188010	SUPPORT SHAFT
217	P28697000	SPRING (IDLE)
341	R12492010	TENSION PLATE B ASSEMBLY

ENGINE ASSEMBLY, CONTINUED




Figure PL1b, Engine Assembly

ENGINE ASSEMBLY (PL1B)		
ITEM	PART NUMBER	PART DESCRIPTION
44	MD4300622	PAN HEAD SCREW
48	MD4400822	PAN HEAD SCREW +SW +WL
66	ND0040030	E SNAP RING
67	ND0050030	E SNAP RING
165	P28129000	SHAFT (PULLEY A/E)
167	P28131000	SHAFT (CUTTER PULLEY)
177	P28147000	SHAFT (CUT PULLEY B)
390	R14230010	PULLEY(69) ASSEMBLY
391	R14231000	PULLEY (55/55) ASSEMBLY TG308
392	R14232000	PULLEY ASSEMBLY TG308
393	R14233010	CUTTER PULLEY (27/27) ASSEMBLY
394	R14234000	CUTTER PULLEY (27) ASSEMBLY
396	R14237000	PULLEY ASSEMBLY
403	R14821000	PULLEY (55/83) ASSEMBLY TG312
404	R15137000	PULLEY ASSEMBLY TG312

ENGINE ASSEMBLY, CONTINUED




Figure PL1c, Engine Assembly

ENGINE ASSEMBLY (PL1C)		
ITEM	PART NUMBER	PART DESCRIPTION
66	ND0040030	E SNAP RING
164	P28128020	SHAFT (FEED ROLLER B)
166	P28130020	ADAPTOR (PLATEN)
244	P32001000	TIMING BELT TG308
245	P32002000	TIMING BELT TG308 TG312
246	P32003000	TIMING BELT TG308 TG312
247	P32004000	TIMING BELT TG308 TG312
248	P32005000	TIMING BELT TG308 TG312
249	P32006000	TIMING BELT TG312
250	P32007000	TIMING BELT TG312
269	P33345000	TIMING BELT TG308

ENGINE ASSEMBLY, CONTINUED




Figure PL1d, Engine Assembly

ENGINE ASSEMBLY (PL1D)		
ITEM	PART NUMBER	PART DESCRIPTION
44	MD4300622	PAN HEAD SCREW
66	ND0040030	E SNAP RING
80	P13863010	TENSION ROLLER
83	PT1112060	BEARING, PLATEN ROLLER (INNER)
139	P28021000	TENSION PLATE C
169	P28133000	TENSION SHAFT B
178	P28158000	TENSION SHAFT C
217	P28697000	SPRING (IDLE)
282	PA3760500	SUPPORTER CLAMP
343	R12497010	TENSION PLATE A ASSEMBLY
344	R12498010	TENSION PLATE C ASSEMBLY
349	R13886000	POWER ROUTE A ASSEMBLY
350	R13887000	POWER ROUTE D ASSEMBLY

SENSOR ASSEMBLY




Figure PL2a, Sensor Assembly

SENSOR ASSEMBLY (PL2A)		
ITEM	PART NUMBER	PART DESCRIPTION
8	JG100011A	TIE WRAP
11	JG100541A	CABLE CLAMP
21	MA0301222	PAN HEAD SCREW (+2JP3012)
25	MA1300622	FLAT HEAD SCREW
33	MD3300822	PAN HEAD SCREW +SW +WS
44	MD4300622	PAN HEAD SCREW +SW +WL
53	MH0300822	PAN HEAD P TIGHT SCREW
54	MH0301221	P TIGHT SCREW
66	ND0040030	E SNAP RING
141	P28030000	SHAFT (SLIDE)
145	P28039010	BRACKET B (S/H SEN)
146	P28040010	BRACKET(C/H SENS)
147	P28041000	SHAFT (SENSOR)
148	P28042010	BRACKET (RACK C/H SENSOR)
189	P28207000	LENS (I MARK)
191	P28209000	RACK B (CENTER)

SENSOR ASSEMBLY (PL2A)		
ITEM	PART NUMBER	PART DESCRIPTION
192	P28212010	SENSOR BR BOTTOM (CENTER HOLE)
193	P28213000	RACK A (CENTER)
263	P32287000	BUSH
277	PA1740901	SENSOR PROTECTOR
280	PA3740300	SENSOR BRACKET
283	PA3761101	SUPPORTER CLAMP
287	PB2760300	COLLAR
292	PE1740400	BRACKET, SENSOR
293	PE1760200	SENSOR PROTECTOR (C)
294	PE1762300	SENSOR PROTECTOR (B)
348	R13745010	BODY B (S/H SEN) ASSEMBLY
351	R13892010	BODY A (S/H SEN) ASSEMBLY
361	R14168000	GAP & CENTER HOLE (U) SENSOR CABLE SET-LF
367	R14174000	GAP & CENTER HOLE (L) SENSOR CABLE SET-LF
370	R14178010	SIDE HOLE (L) SENSOR CABLE SET-LF
395	R14236010	FRAME ASSEMBLY

SENSOR ASSEMBLY, CONTINUED




Figure PL2b, Sensor Assembly

SENSOR ASSEMBLY (PL2B)		
ITEM	PART NUMBER	PART DESCRIPTION
21	MA0301222	PAN HEAD SCREW (+2JP3012)
29	MC0301622	PAN HEAD SCREW
32	MD3300622	PAN HEAD SCREW +SW +WS
43	MD4300522	PAN HEAD SCREW +SW +WL
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW
46	MD4301022	PAN HEAD SCREW +SW +WL
48	MD4400822	PAN HEAD SCREW +SW +WL
51	MH0300522	PAN HEAD P TIGHT SCREW
55	MH1200522	FLAT HEAD P TIGHT SCREW
63	MT1300522	HEXAGON NUT (2N3X0.5)
65	ND0030030	E SNAP RING E350
66	ND0040030	E SNAP RING
94	P25440010	SENSOR COVER (I MARK)
99	P25546000	LOCK COLLAR (HEAD)

SENSOR ASSEMBLY (PL2B)		
ITEM	PART NUMBER	PART DESCRIPTION
142	P28032010	PAPER GUIDE B
144	P28037000	PAPER GUIDE (FEED A)
149	P28044010	FRAME (SUPPORT A)
150	P28045000	SHAFT (SENSOR GEAR)
151	P28046000	BRACKET (JUMP SENSOR)
152	P28047010	OPEN SENSOR BR
170	P28137000	GEAR PULLEY_B (34/17)
190	P28208000	SUB GUIDE (A)
205	P28330010	SHAFT (LOCK COLLAR)
233	P29730000	FEED LOCK B
234	P29731020	SHAFT (LATCH LOCK)
235	P29732010	SPRING (F/B LOCK)
263	P32287000	BUSH
284	PA3761700	KEYBOARD BRACKET (B)
298	PE2750400	COLLAR
299	PE5A21700	HEAD OPEN KNOB
347	R13583000	FEED LOCK ASSEMBLY
362	R14169000	IM & EDGE SENSOR CABLE SET-LF
364	R14171000	AF & J-HOLE (U) SENSOR CABLE SET-LF
373	R14181000	LITTLUCH SENSOR CABLE SET-LF
409	P40559000	SPRING (PAPER GUIDE)

HEAD ASSEMBLY




Figure PL3a, Head Assembly

HEAD ASSEMBLY (PL3A)		
ITEM	PART NUMBER	PART DESCRIPTION
26	MA2300522	BIND HEAD SCREW
27	MA2300622	BIND HEAD SCREW
34	MD3301222	PAN HEAD SCREW
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW
63	MT1300522	HEXAGON NUT (2N3X0.5)
65	ND0030030	E SNAP RING
66	ND0040030	E SNAP RING
67	ND0050030	E SNAP RING
68	ND0060030	E RING
75	P11232200	PR KNOB
85	P22186000	POLY SLIDER
96	P25492010	SPRING (HEAD ONE TOUCH)
103	P27709030	SHAFT (HEAD PRESSURE C)
104	P27715020	SHAFT (HEAD ADJUST)
105	P27716010	SHAFT (HEAD MAIN)

HEAD ASSEMBLY (PL3A)		
ITEM	PART NUMBER	PART DESCRIPTION
106	P27717000	SHAFT (PRESSURE B)
107	P27719000	KNOB (HEAD)
108	P27773000	HEAD PRESSURE BR (A)
116	P27837000	RIBBON PLATE
118	P27868000	CAM A (HEAD)
119	P27869000	CAM B (HEAD)
120	P27874010	KNOB A (HEAD)
121	P27876000	BUSH A (HEAD)
122	P27877010	SPRING (HEAD OPEN)
123	P27879010	COLLAR (PRESSURE SHAFT)
252	P32010000	PLASTIC WASHER
259	P32069001	KNOB (HEAD PRESSURE)
270	P34438000	PLASTIC WASHER
329	Q02514000	STICKER(HEAD AJ)
337	R12366010	HEAD TOP BR ASSEMBLY
338	R12367010	HEAD BRACKET ASSEMBLY
384	R14221020	HEAD FRAME ASSEMBLY
397	R14238000	SHAFT ASSEMBLY (HEAD STAY)

HEAD ASSEMBLY, CONTINUED




Figure PL3b, Head Assembly

HEAD ASSEMBLY (PL3B)		
ITEM	PART NUMBER	PART DESCRIPTION
37	MD3302522	PAN HEAD SCREW+SW+WS
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW
63	MT1300522	HEXAGON NUT
79	P11949000	ANTI STATIC SHEET
82	P17118000	SPRING CAP
117	P27839000	PLATE (LATCH HANDLE)
124	P27880010	COLLAR (HANDLE)
125	P27881000	SPACER (LATCH HANDLE)
126	P27882000	COVER (LATCH HANDLE)
127	P27883000	COVER (PRESSURE SHAFT)
128	P27884010	HANDLE_DANTUKINEJI
136	P28000010	POWER ROUTE (BASE) B
273	P31946000	SPRING (HEAD PRESS) C
358	R14165000	POWER & HEAD CABLE SET-LF
359	R14166000	HEAD CABLE SET-LF

HEAD ASSEMBLY (PL3B)		
ITEM	PART NUMBER	PART DESCRIPTION
385	R14222000	PRINT HEAD (8 DPMM)TG308
386	R14223000	PRINT HEAD (12 DPMM) TG312
397	R14238000	SHAFT ASSEMBLY (HEAD STAY)

CUTTER ASSEMBLY




Figure PL4a, Cutter Assembly

CUTTER ASSEMBLY (PL4A)		
ITEM	PART NUMBER	PART DESCRIPTION
8	JG100011A	TIE WRAP
14	K00287000	CUTTER MOTOR
25	MA1300622	FLAT HEAD SCREW
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW
53	MH0300822	PAN HEAD P TIGHT SCREW
58	MJ1300328	HEX SOCKET SET SCREW (W-POINT)
93	P25397000	SHAFT (CUTTER SENSOR)
112	P27784000	SENSOR BR (CUTTER)
113	R18294000	CUTTER SENSOR BR SET (TG)
114	R18228000	SENSOR COVER SET
115	P27788010	CUTTER BRACKET
186	P28172000	SENSOR COVER A(CUTTER)
240	P31836010	POST SCREW
243	P31920000	CUTTER ASSEMBLY
279	PA2760100	SENSOR COVER

CUTTER ASSEMBLY (PL4A)		
ITEM	PART NUMBER	PART DESCRIPTION
288	PB2760400	THERMO SCREW
291	PE1690301	CUT SENSOR COVER
296	PE2680900	SPACER
301	PL1760100	PULLEY
312	PT9761000	PAN HEAD SCREW
352	R14107000	CUTTER TAG SENSOR (L) SET-LF
355	R14137000	CUT PCB SET-LF
375	R14184000	CUTTER POSITION SENSOR CABLE SET-LF
377	R14186000	CUTTER SENSOR (U) CABLE SET-LF

CUTTER ASSEMBLY, CONTINUED




Figure PL4b, Cutter Assembly

CUTTER ASSEMBLY (PL4B)		
ITEM	PART NUMBER	PART DESCRIPTION
36	MD3302022	PAN HEAD SCREW
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW
66	ND0040030	E SNAP RING
67	ND0050030	E SNAP RING
83	PT1112060	BEARING, PLATEN ROLLER (INNER)
91	P25153010	CUTTER ROLLER (20X89)
100	P25561010	BRACKET (CUT ROLLER)
109	P27780000	SHAFT (CUTTER OKURI)
222	P28811020	CUTTER COVER
236	P29794010	SHAFT (CUTTER ROLLER)
239	P31090010	CUTTER COVER PLATE
271	P34471000	SHEET (THUNDERON)
290	PC1760400	SPRING
388	R14226000	CUTTER ROLLER ASSEMBLY
389	R14227000	CUTTER PULLEY ASSEMBLY

FEED ASSEMBLY




Figure PL5a, Feed Assembly

FEED ASSEMBLY (PL5A)		
ITEM	PART NUMBER	PART DESCRIPTION
24	MA1250622	FLAT HEAD SCREW
32	MD3300622	PAN HEAD SCREW +SW +WS
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW
46	MD4301022	PAN HEAD SCREW +SW +WL
50	MD4401222	PAN HEAD SCREW +SW +WL
52	MH0300622	P TIGHT SCREW
66	ND0040030	E SNAP RING
90	P24998010	SHAFT (IDLE B)
132	P27904000	PLATE (OPEN LOCK)
156	P28057010	BRACKET (FEED ROLLER)
157	P28058000	SHAFT (FEED ROLLER)
188	P28205000	LENS (SIDE HOLE)
196	R18311000	FEED ROLLER (UPPER) S/A
197	P28219000	SENSOR BR (JUMP HOLE)
208	P28338010	SHAFT (SUPPORT)

FEED ASSEMBLY (PL5A)		
ITEM	PART NUMBER	PART DESCRIPTION
210	P28363000	FRAME SUPPORT A
215	P28694000	SPRING (FEED ROLLER)
231	P28847020	ENGINE FRAME
232	P29726010	FEED COVER (BOTTOM)
241	P31846000	SHAFT (PULLEY R)
297	PE2730300	STOPPER COLLAR
302	PL2720100	ADJUST COLLAR
336	QC6A20200	PUSH LABEL
340	R12486020	FEED COVER ASSEMBLY
379	R14198000	SIDE HOLE (U) SENSOR CABLE SET-LF
380	R14203000	AF & J-HOLE (U) SENSOR SUB CABLE SET-LF

FEED ASSEMBLY, CONTINUED




Figure PL5b, Feed Assembly

FEED ASSEMBLY (PL5B)		
ITEM	PART NUMBER	PART DESCRIPTION
24	MA1250622	FLAT HEAD SCREW
26	MA2300522	BIND HEAD SCREW
32	MD3300622	PAN HEAD SCREW +SW +WS
39	MD3400822	PAN HEAD SCREW +SW +WS
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW +SW +WL
46	MD4301022	PAN HEAD SCREW +SW +WL
50	MD4401222	PAN HEAD SCREW +SW +WL
52	MH0300622	P TIGHT SCREW
53	MH0300822	PAN HEAD P TIGHT SCREW
132	P27904000	PLATE (OPEN LOCK)
154	P28053000	PLATE (F/R POSITION)
159	P28063000	SHAFT (LID LATCH)
204	P28317010	RFID CASE
206	P28331000	PAPER GUIDE (RFID)
209	P28362000	PAPER GUIDE (LABEL SENSOR)

FEED ASSEMBLY (PL5B)		
ITEM	PART NUMBER	PART DESCRIPTION
211	P28365000	CUTTER BRACKET B
212	P28366010	SENSOR HOLDER (CORNER R)
213	P28367000	SENSOR HOLDER COVER (CORNER R)
216	P28695000	SPRING (LATCH OPEN)
218	P28797000	SWITCH PLATE
242	P31914000	SPRING (PLUNGER)
255	P32019000	PLASTIC WASHER
257	P32023000	BALL
260	P32109000	DISK BRAKE
285	PA3766700	RIBBON SENSOR BRACKET
286	PB1763700	SHAFT (PAPER GUIDE)
315	PV2760100	RUBBER FOOT
346	R12657000	BASE COVER (INSERT)
356	R14163000	KB CABLE SET-LF
365	R14172000	RIBBON SENSOR-1 CABLE SET-LF
366	R14173000	HEAD OPEN SENSOR CABLE SET-LF
371	R14179000	EDGE (U) SENSOR CABLE SET-LF
372	R14180000	RIBBON SENSOR-2 CABLE SET-LF
376	R14185000	CUTTER SENSOR (L) CABLE SET-LF
378	R14187003	AC LINE CABLE SET-LF

RIBBON ASSEMBLY




Figure PL6a, Ribbon Assembly

RIBBON ASSEMBLY (PL6A)		
ITEM	PART NUMBER	PART DESCRIPTION
18	MA0300622	PAN HEAD SCREW
42	MD3401422	PAN HEAD SCREW
44	MD4300622	PAN HEAD SCREW
51	MH0300522	PAN HEAD P TIGHT SCREW
66	ND0040030	E SNAP RING
68	ND0060030	E RING
69	ND0080030	E-SNAP RING
72	P00170000	ONE-WAY LIMITER
76	P11283000	DISK PLATE TL
77	P11305010	GRIP SHEET
78	P11461000	ONE-WAY CLUTCH
80	P13863010	TENSION ROLLER
87	P22568000	SPRING (CLIP)
88	P22892000	SPRING (RELEASE)
89	P23675000	KNOB

RIBBON ASSEMBLY (PL6A)		
ITEM	PART NUMBER	PART DESCRIPTION
92	P25384000	SHAFT (SLIDE LONG)
138	P28005000	TENSION PLATE A
173	P28140000	GEAR PULLEY_K (83/83)
201	P28231010	RIBBON SHAFT C
202	P28277000	RIBBON CORE A
203	P28278000	RIBBON CORE B
217	P28697000	SPRING (IDLE)
237	P30322000	TORQUE LIMITER
251	P32009000	TIMING BELT
261	P32285000	SPRING (SLIDE)
274	P37081000	GRIP SHEET
306	PT1116060	BALL BEARING
319	Q01840010	STICKER (LOCK)
321	Q02428000	ACETATE TAPE
341	R12492010	TENSION PLATE B ASSEMBLY
391	R14231000	PULLEY (55/55) ASSEMBLY TG308

RIBBON ASSEMBLY, CONTINUED




Figure PL6b, Ribbon Assembly

RIBBON ASSEMBLY (PL6B)		
ITEM	PART NUMBER	PART DESCRIPTION
16	MA0200822	PAN HEAD SCREW
28	MA2400828	BIND HEAD SCREW
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW
51	MH0300522	PAN HEAD P TIGHT SCREW
67	ND0050030	E SNAP RING
68	ND0060030	E RING
69	ND0080030	E-SNAP RING
71	P00005000	TORQUE LIMITER
83	PT1112060	BEARING, PLATEN ROLLER (INNER)
86	P22505000	ONE-WAY CLUTCH FOR DISPENSER
130	P27901000	FRAME (RIBBON)
133	P27906000	BRACKET (RIBBON UW A)
162	P28087020	RIBBON SHAFT A
171	P28138000	RIBBON GEAR_I (20)
172	P28139000	RIBBON GEAR_J (50)

RIBBON ASSEMBLY (PL6B)		
ITEM	PART NUMBER	PART DESCRIPTION
174	P28141000	PULLEY_L(54)
175	P28142000	GEAR PULLEY_M (54/54)
195	P28217020	RIBBON FEED ROLLER
198	P28220000	RIBBON SHAFT B
199	P28221000	BF STOPPER RIBBON
207	P28335010	SHAFT(GEAR PULLEY)
267	P32845000	TIMING BELT
276	PA1731000	ADJUST PLATE
281	PA3760500	SUPPORTER CLAMP
300	PE7720150	DISK PLATE(A)
305	PT1112060	BEARING, PLATEN ROLLER (INNER)
306	PT1116060	BALL BEARING
307	PT1116080	BALL SUPPORTER
314	PT9A20600	TORQUE LIMITER

FRAME ASSEMBLY




Figure PL7a, Frame Assembly

FRAME ASSEMBLY (PL7A)		
ITEM	PART NUMBER	PART DESCRIPTION
12	K00250000	POWER SUPPLY (Universal) TG3XX
28	MA2400828	BIND HEAD SCREW
39	MD3400822	PAN HEAD SCREW +SW +WS
43	MD4300522	PAN HEAD SCREW +SW +WL
45	MD4300822	PAN HEAD SCREW +SW +WL
48	MD4400822	PAN HEAD SCREW +SW +WL
49	MD4401022	PAN HEAD SCREW +SW +WL
81	P16092000	BEARING CLAMP
140	P28028010	PAPER GUIDE A
158	P28059000	PAPER GUIDE (FEED B)
225	P28819000	LABEL COVER RH
307	PT1116080	BALL SUPPORTER
315	PV2760100	RUBBER FOOT
342	R12496010	FRAME (LABEL)ASSEMBLY

FRAME ASSEMBLY, CONTINUED




Figure PL7b, Frame Assembly

FRAME ASSEMBLY (PL7B)		
ITEM	PART NUMBER	PART DESCRIPTION
16	MA0200822	PAN HEAD SCREW
39	MD3400822	PAN HEAD SCREW +SW +WS
44	MD4300622	PAN HEAD SCREW +SW +WL
45	MD4300822	PAN HEAD SCREW +SW +WL
48	MD4400822	PAN HEAD SCREW +SW +WL
53	MH0300822	PAN HEAD P TIGHT SCREW
59	MJ1300528	HEXAGON SOCKET HEAD CAP SCREW (W POINT)
63	MT1300522	HEXAGON NUT
64	ND0020030	E SNAP RING
70	ND3160024	C-SNAP RING
81	P16092000	BEARING CLAMP
83	PT1112060	BEARING, PLATEN ROLLER (INNER)
84	P32016000	TORQUE LIMITER
95	P25491000	SPRING (SHIWAKE MARK)
98	P25502000	SPRING (LABEL GUIDE)

FRAME ASSEMBLY (PL7B)		
ITEM	PART NUMBER	PART DESCRIPTION
129	P27900000	BRACKET (SOLENOID)
131	P27902000	SHAFT BASE (LABEL)
134	P27908000	BRACKET (INK ROLLER)
137	P28003020	SHAFT (SOLTING)
153	P28052000	PLATE (BEARING)
155	P28054040	FEED ROLLER TG308
160	P28085010	SHAFT (LABEL)
161	P28086000	SHAFT (LABEL SLIDE)
179	P28161000	LABEL GUIDE A
181	P28163020	LABEL BOSS
182	P28164000	LABEL GUIDE B
183	P28165010	LABEL GUIDE C
184	P28166010	LABEL GUIDE BOSS
185	P28167010	LABEL GUIDE LOCK
194	P28216010	INK ROLLER COVER
200	P28227000	PLATEN ROLLER TG3XX
214	P28693000	SPRING (INK ADJUST)
219	P28808020	FRONT COVER (LCD)
220	P28809000	LED COVER
221	P28810000	LENS (LED)
228	P28824000	BUTTON A
229	P28825001	BUTTON B
230	P28826000	BUTTON C
254	P32017000	BALL SUPPORTER
256	P32022000	BUSH
258	P32061000	LABEL BOSS COVER
264	P32745000	KNURLING SCREW M3*10
265	P32581000	BUSH
266	P32582000	BUSH
292	PE1740400	SENSOR BRACKET (TOP)
307	PT1116080	BALL SUPPORTER
308	PT1117050	BALL BEARING
354	R14136000	KB PCB ASSEMBLY-LF
398	R14253000	SOLENOID SET-LF
400	R14326000	LCD COVER (SILK) TG

FRAME ASSEMBLY, CONTINUED




Figure PL7c, Frame Assembly

FRAME ASSEMBLY (PL7C)		
ITEM	PART NUMBER	PART DESCRIPTION
1	CV617431A	IC REAL TIME CLOCK DALLAS
19	MA0300822	PAN HEAD SCREW
44	MD4300622	PAN HEAD SCREW
45	MD4300822	PAN HEAD SCREW
46	MD4301022	PAN HEAD SCREW +SW +WL
54	MH0301221	P TIGHT SCREW
57	MH1300621	P TIGHT SCREW
58	MJ1300328	HEX SOCKET SET SCREW (W-POINT)
73	P11115000	GUIDE RAIL
74	P11136100	COVER (OP./F)
110	P27782000	SHAFT (CUTTER KNOB)
111	P27783000	KNOB (CUTTER)
223	P28813010	UPPER COVER
224	P28814000	REAR COVER
226	P28820010	LABEL COVER LH
227	P28821010	LABEL REAR COVER

FRAME ASSEMBLY (PL7C)		
ITEM	PART NUMBER	PART DESCRIPTION
238	P30916000	BLIND PLATE
278	PA1770100	SHIELD PLATE
311	PT9751200	TWIST LOCK
320	Q02436000	STICKER (ROUTE)TG
331	Q02862000	STICKER (CABLE)
345	R12579000	SIMPLE INPUT DEVICE - CONTROL PCB-LF
357	R14164000	SID CABLE SET_ST-LF
360	R14167001	SENSOR CABLE (SEN) SET-LF
368	R14175001	SENSOR CABLE (TAG)SET-LF
374	R14183000	OPTION CABLE SET-LF
381	R14213020	CONT BR ASSEMBLY
383	R14217020	OPEN COVER B (SILK)
399	R14287000	CONT PCB TG3XX

ATTACHMENT ASSEMBLY




Figure PL8, Attachment Assembly

ATTACHMENT ASSEMBLY (PL8)		
ITEM	PART NUMBER	PART DESCRIPTION
3	H00878000	POWER CORD (EX1)
52	MH0300622	P TIGHT SCREW
180	P28162010	LABEL ADAPTER

