



Parts List

For printer models:

CT4i Series



PN: 9001241(B)

SATO America, Inc.

**10350A Nations Ford Road
Charlotte, NC 28273**

Main Phone: (704) 644-1650

Technical Support: (704) 644-1660

Technical Support Fax: (704) 644-1661

E-Mail: satosales@satoamerica.com

www.satoamerica.com

© SATO America, Inc. 2011

All rights reserved.

BASE COVER ASSEMBLY




Figure PL1a, Base Cover Assembly

BASE COVER ASSEMBLY, CONTINUED




Figure PL1b, Base Cover Assembly

BASE COVER ASSEMBLY, CONTINUED




Figure PL1c, Base Cover Assembly

BASE COVER ASSEMBLY, CONTINUED




Figure PL1d, Base Cover Assembly

BASE COVER ASSEMBLY, CONTINUED




Figure PL1e, Base Cover Assembly

BASE COVER ASSEMBLY, CONTINUED




Figure PL1f, Base Cover Assembly

RIBBON ASSEMBLY




Figure , Ribbon Assembly

FRAME ASSEMBLY





Figure PL3a, Frame Assembly



ATTACHMENT ASSEMBLY




Figure PL5a, Attachment Assembly

ALL ASSEMBLIES (PL1A THROUGH PL5A)		
ITEM	PART NUMBER	PART DESCRIPTION
1	MA0300622	PAN HEAD SCREW
2	F00177000	PHOTO INTERRUPTER -LF
3	MH0301022	PAN HEAD P TIGHT SCREW
4	PE6A21900	MICRO DRIVER
5	MA0300822	PAN HEAD SCREW
6	P28075000	SHAFT(LABEL GUIDE)
7	P18335010	LABEL CENTER GUIDE
8	MH9300822	PAN HEAD P TIGHT SCREW
9	PJ0A20500	GEAR(L.GUIDE)
10	P26948000	BOTTOM CABINET
11	P18339000	OPEN LEVER
13	P10724200	RFID COVER
14	R08352010	HEAD OPEN CABLE ASSY -LF
15	MH0250625	PAN HEAD P TIGHT SCREW
16	MH1300825	FLAT HEAD P TIGHT SCREW
17	ND0025030	E SNAP RING
18	PA2A20000	GUIDE COVER
19	PA4A20000	PLATE SPRING (G)
20	PB0A20500	LABEL SHAFT
21	PB0A20600	FLAP SHAFT
22	PC1A20100	SPRING(FLAP)
23	PE3A20100	LABEL COLLAR
24	P26947000	GUIDE FLAP
25	P26946000	LABEL GUIDE(L)
26	P26945000	LABEL GUIDE(R)
27	PE5A21402	SENSOR COVER
28	P18333000	GUIDE STOPPER
29	R04681000	PITCH SENSOR-A-LF
30	R04683000	PITCH SENSOR-B ASSY-LF
31	R04684000	RELAY PB ASSY-LF
32	R12102000	FRONT COVER SET
33	R08317000	FRONT PANEL(SILK)
34	P18330002	BUTTON
35	PR4A20700	COVER(DSW/VOL)
36	R04726001	PLATEN ROLLER SUB CT4XXi
38	PE0A20000	FOOT
39	P18324001	BOTTOM CASE

ALL ASSEMBLIES (PL1A THROUGH PL5A)		
ITEM	PART NUMBER	PART DESCRIPTION
40	P18329010	IF COVER(BOTTOM)
41	P18334310	IF COVER (USB+RS232C)
	P18334200	IF COVER (USB+LAN)
42	J00040000	NYLON CLAMP
44	P18338000	LENS
45	R04685000	CONTROL PANEL ASSY-LF
46	PA6A20000	POWER SW.BR.
47	R08353001	POWER CABLE ASSY -LF
48	MH0300628	PAN HEAD P TIGHT SCREW
49	N00013000	POST -LF
50	R10656002	MAIN PCB EX1 USB+RS232C CT4XXi
51	R10653002	MAIN PCB EX1-6 USB+LAN CT4XXi
52	R10655000	SET PCB SET -LF
53	R10866000	SUB1 PCB SET -LF
54	WWCT55070	BLUETOOTH INTERFACE CT4XXi
55	R05337011	IEEE1284 BOARD ASSY-LF
58	P18331000	COVER(CABLE)
59	R12092000	HEAD CABLE ASSY-LF
60	R12788000	TOP CABINET(SILK)DT
61	P18325000	COVER(UW)
62	R04731020	SHAFT(HINGE L)
63	R08331000	CLUTCH(HINGE)
64	M16247000	FLAT HEAD P-TAP SCREW
65	ND0070022	E SNAP RING
67	P10302010	SHAFT (HINGE R)
68	P12748010	SPRING (DAMPER)
69	Q02072000	STICKER(ROUTE)
71	P10723200	HOLDER(HINGE SHAFT)
72	R09760000	SHAFT(HINGE L)
73	R12094000	HEAD CABLE ASSY(R) -LF
74	MH0300622	BIND P TIGHT SCREW
76	P19950030	COVER HOOK(ST)
77	P19955031	SWING ARM
78	P20127002	SWING STOPPER LH
79	P20129002	SWING STOPPER RH
80	P20135001	COVER(UW)
81	P20350000	SPRING(COVER HOOK)

ALL ASSEMBLIES (PL1A THROUGH PL5A)		
ITEM	PART NUMBER	PART DESCRIPTION
82	P20356010	TORSION SPRING LH
83	P20357010	TORSION SPRING RH
84	R09763000	CORE ADAPTER ASSY
85	R12103010	TOP CABINET TT SA
86	R10191000	LABEL ROLLER SA
87	MD4300825	PAN HEAD SCREW+SW+WL
89	MH0300622	PAN HEAD P TIGHT SCREW
90	M16221000	BIND HEAD P TIGHT SCREW
92	MH1300822	FLAT HEAD P TIGHT SCREW
94	ND0030022	E RING 3
95	NG3161230	SPRING PIN
96	P19948001	CAP
97	P19953001	ROLLER
98	P19957001	SPRING GUIDE
99	P19959010	ANTI STATIC PLATE
100	P19961001	BACKUP PLATE
101	P19962010	HEAD HOOK
102	P19967000	GEAR A(Z36)
103	P19968000	GEAR B(Z20/40)
104	P19971000	STOPPER(FRAME)
105	P19973002	TORSION GUIDE
106	P19974030	COVER(FRAME LH)
107	P20110003	CORE GUIDE
108	P20114003	FG PLATE
109	P20116002	BUSHING
110	P20117000	GEAR C(Z64)
111	P20130000	SLIDER
112	P20333000	SPRING(CORE GUIDE W)
113	P20334000	SPRING(BACKUP)
114	P20337000	SPRING(HEAD)
115	P20340000	SPRING(HEAD HOOK)
116	P20345000	SPRING(RIBBON ASSY)
117	P20355000	SPRING(COVER)
118	P21590020	SHAFT HOLDER
119	P21596010	STOPPER(GEAR)
120	P21695000	SPRING(CORE GUIDE S)
121	P22352000	RIBBON SHAFT(REAR)

ALL ASSEMBLIES (PL1A THROUGH PL5A)		
ITEM	PART NUMBER	PART DESCRIPTION
122	P22386000	HOLDER(R-SHAFT REAR)
123	P22403000	COVER(TORQUE LIMITER)
124	P22422000	SENSOR PLATE
125	P22505000	ONEWAY CLUTCH
126	P29125000	TORSION SPRING
127	P22581000	TORQUE LIMITER
128	PB0A22601	FRONT SHAFT
129	PT9A20600	TORQUE LIMITER
130	R09453001	HEAD ADJUSTER SET
131	R09456030	RIBBON FRAME SET
132	R12467000	FRAME RH SET
133	R12469001	FRAME LH SET
134	R09800000	RIBBON SHAFT ASSY
135	R09935000	RIBBON END SENSOR ASSY -LF
136	P22812000	SPRING(GEAR STOPPER)
137	P25315000	SPRING(FRONT)
138	JG100541A	CKN CLAMP
139	K00081000	STEPPING MOTOR
140	MD3300622	PAN HEAD SCREW+SW+WS
141	ND0020022	E-SNAP RING
143	P02367000	HEAT CONDUCTION PAD
144	P10261010	SPRING (HEAD LOCK)
145	P18341000	ENGINE FRAME
146	P14224000	COLLAR (HEAD LOCK)
147	P10713010	HEAD LOCK ARM
148	PA3A20300	HEAT SINK (MOTOR)
149	PJ0A20301	DOUBLE GEAR (8)
150	PJ0A20401	IDLE GEAR
151	PR1A20002	MOTOR PLATE SET
152	PJ0A20101	DOUBLE GEAR (12)
156	P10260000	SPRING (HEAD)
157	P10262000	PLATE SPRING (HEAD)
158	P10264000	SPRING (LEVER)
159	P18890000	RELEASE LEVER
160	P10281000	COLLAR (3.1*5*3)
161	P10282000	SHAFT (TURN ROLLER)
162	P10284001	CUTTER STAY

ALL ASSEMBLIES (PL1A THROUGH PL5A)		
ITEM	PART NUMBER	PART DESCRIPTION
163	P10285000	ANTI STATIC SHEET
164	P10299000	SHAFT (H.PRESSURE)
165	P10715000	P SHAFT BR
166	P15922200	FRONT LABEL GUIDE
167	PE3A20000	TURN ROLLER(5.10*6*29)
168	R04268000	HEAD TOP BR SET
169	R04269310	HEAD BR SET
170	MD0260522	PAN SCREW+SW
171	R04733001	PRINT HEAD (8) CT408iDT
172	R08329100	PRINT HEAD (12) CT412iDT
173	R10168000	PRINT HEAD (8) CT408iTT
174	R10169000	PRINT HEAD (12) CT412iTT
175	R10170000	PRINT HEAD (24) CT424iTT
176	R12108000	PRINT HEAD (24) CT424iDT
177	Q00029000	LAPPING SHEET SET(4W)
178	JH000441A	AC CABLE(1-)
182	K00262000	AC ADAPTOR CT4XXi (EX1)
183	R12198000	USB CABLE -LF
190	MD4300825	PAN HEAD SCREW+SW+WL
191	R11925001	HEAD CABLE ASSY(24R) -LF
192	R11927000	HEAD CABLE ASSY -LF
193	P25347000	SENSOR RIB(COVER OPEN)
194	P20340000	SPRING(HEAD HOOK)
195	P28065000	SPACER SHEET

