

CL4NX Plus Rotary Cutter Kit

Installation Manual



This Installation Manual explains how to install Rotary Cutter Kit (hereafter referred to as "the product"). Read the restrictions and precautions when installing.

For details on how to use Rotary Cutter Kit and how to use and operate CL4NX Plus setting items, see CL4NX Plus web manual "Operator Manual".

SATO CORPORATION

Website http://www.satoworldwide.com/



First edition: Feb. 2020 Q05346500 ©2020 SATO Corporation

Safety Precautions

This section describes how to use the product safely. Be sure to read the following information carefully before using the product.

Pictographic Symbols

This installation manual uses a variety of pictographic symbols. These symbols emphasize the safe and correct use of the product and to prevent injury to others and property damage. The explanation of the symbols is as follows. Be sure to understand these symbols well before you read the main text.

Ignoring the instructions marked by this symbol and erroneously operating the product could result in death or serious injury.
Ignoring the instructions marked by this symbol and erroneously operating the product could result in injury or property damage.

Symbol example



The \bigtriangleup pictograph means "Caution is required". A specific warning symbol is contained inside this pictograph.

The \bigotimes pictograph means "Should not be done". What is specifically prohibited is





Do not touch or insert any object in the cutter

Do not touch the cutter with your hands or insert foreign objects other than media into the cutter. Doing so could result in injury.

Do not power on/power off the product or plug/unplug the power cord and other cables with wet hands. Doing so could result in electric shock or damage.

Power cord and other cables

Do not operate with wet hands



- Grab a power cord and other cables by the plug when removing from the outlet or connector port. Removing a power cord and other cables by grabbing the cord/cable area could result in exposure of wires, breakage, fire, electric shock, or damage.
- Do not place the power cord and other cables near a heater or other sources of heat. Doing so could result in melting of the power cord and other cables sheathing, fire, electric shock, or damage.

Handling

Some parts of the product are sharp. Be careful not to get injured.

Precautions on Installation and Handling

- For details on the restrictions and precautions on installation of CL4NX Plus, see the CL4NX Plus web manual "Operator Manual".
- The product works with 1.12.0 version firmware build or later. Check the firmware version shown on the [Information] Menu > [Build Version] screen of CL4NX Plus. Contact your SATO reseller or technical support for availability of the latest firmware.

Accessories





contained in or near the pictograph.



The ● pictograph means "Must be done". What is specifically to be done is contained in the pictograph.

Do not place in high-temperature locations



Do not place the product near heating equipment such as cooking appliances or a heater, or in high-temperature locations. Doing so could damage the product or result in a fire or electric shock.

Connecting cables or optional devices

• When connecting a cable or optional device to the product, be sure to turn off each of the devices. If they are connected with the power on, an optional device could move unexpectedly, resulting in injury, electric shock, or damage.



- When installing a cable or optional device, be sure not to make a mistake in the orientation and steps to install. Otherwise, it could result in injury, fire, electric shock, or damage.
- Do not use cables other than the ones supplied with the product or recommended by us. Doing so could result in smoke, fire, electric shock, or damage.

(d) Black screws for fixing the cover (2 pcs)

Required tool

· Phillips screwdriver (JIS #2 or equivalent)

Installing the Cutter Unit

Make sure that the CL4NX Plus is powered off and disconnect the power cord from the AC outlet.

2 Open the top cover and push the head lock lever towards the rear to unlock the print head.

Тір

Open the top cover fully to prevent accidental drop of the cover.



3 Remove the front covers of CL4NX Plus.

- Remove the two screws.
- Slide out in the direction of the arrow to remove the right and left front covers.



4 Connect the relay PCB to the CL4NX Plus and fix it with screws **a**.

▲ Discharge static electricity through a metal object before touching the relay PCB. Failure to do so can damage the relay PCB.

① Pull out the option cable from the CL4NX Plus.



- ② Attach the supplied cutter cable to the relay PCB.
- ③ Attach the option cable pull out from the CL4NX Plus to the relay PCB.

Tip If the option cable has a heat shrink tube, remove the heat shrink tube first. Be sure not to cut or damage the cable when you cut the heat shrink tube.

④ Insert the relay PCB with the cables attached in to the CL4NX Plus as shown in the figure.



5 Attach the bracket to the CL4NX Plus with screws (b) (three places).



6 Connect the cutter cable of the relay PCB to the cutter unit.

Tip

If it is difficult to connect the cutter cable, remove the protective cover. After connecting, be sure to reattach the protective cover.



② Insert the projection of the cutter unit into the hole of the bracket attached to CL4NX Plus to locate the cutter unit to the appropriate position.



③ Fix the cutter unit in four places with two screws ⓒ and two other screws of the cutter unit.



8 Attach the cover.

- ① Hook the right side of the cover onto the CL4NX Plus.
- ② Push the left side of the cover toward the CL4NX Plus.
- ③ Slide the cover to the left.



④ Secure the cover with the two screws @.





7 Align the cutter unit and fix it with screws ©.

 As shown in the figure, pass the cables through the groove of the bracket and press lightly.



Configuring CL4NX Plus

To print using the cutter, select [Cutter] or [Cut & Print] on the [Print Mode] menu of the CL4NX Plus.

See the CL4NX Plus web manual "Operator Manual" for details.